





Image is for illustration purpose only

DIESEL GENERATOR

FUEL OPTIMISED

ELECTRICAL

			Pri	me	Star	ndby	
Frequency (Hz)	Phases	Voltage (V)	kVA	kW	kVA	kW	Rated Speed (RPM)
50	3	400/230V	58.7	47.0	64.6	51.7	1500
60	3	380/220V	63.0	50.4	69.3	55.4	1800
60	3	220/127V	71.0	56.8	78.1	62.5	1800
60	3	208/120V	71.0	56.8	78.1	62.5	1800

POWER FACTOR	
3 Phase	0.8
I Phase	1

ALL RATINGS ARE TO STANDARD REFERENCE CONDITIONS ISO 8528

Prime: This rating is for the supply of continuous electrical power, at variable load, in lieu of commercially purchase power. There is no limitation on the annual hours of operation and 10% over load power can be supplied for 1 hour in 12.

Standby: Standby Power (ESP) is the maximum output available, for up to 200 hours per year, where the average load (variable) does not exceed 70% of the standby power rating. No overload is available.

Stage IIIA Models are only emissions compliant at 50Hz Prime Power in accordance with 97-68EC.



FUEL CONSUMPTION			
100% Load Prime	L/h		14.1
75% Load Prime	L/h	50Hz	10.60
50% Load Prime	L/h	SUHZ	8.20
100% Load Standby	L/h		15.30
100% Load Prime	L/h		17.60
75% Load Prime	L/h	60Hz	13.24
50% Load Prime	L/h	001 12	10.12
100% Load Standby	L/h		19.10
EXHAUST SYSTEM			
Maximum Temperature 100% Standby	°C		542.00
Exhaust Gas Flow 100% Standby	m ^{3/} min	50Hz	14.00
Maximum Allowed Back Pressure	mbar		100.00
Maximum Temperature 100% Standby	°C		547
Exhaust Gas Flow 100% Standby	m ^{3/} min	60Hz	16.60
Maximum Allowed Back Pressure	mbar		100.00
AIR SYSTEM			
Intake Air Flow 100% Standby	Kg/h		367.00
Total Cooling Air Flow 100% Standby (@ 13 mm H ₂ 0 Canopy Depression)	m³/s	50Hz	3.3
Alternator Fan Airflow	m³/s		0.20
Intake Air Flow 100% Standby	Kg/h		370.00
Total Cooling Air Flow 100% Standby (@ 16 mm H ₂ 0 Canopy Depression)	m³/s	60Hz	3.96
Alternator Fan Airflow	m³/s		0.24

ENGINE				
I500 RPM				
Gross Engine Power (PRP)	kW	56.00		
Gross Engine Power (Standby)	kW	61.60		
	I800 RPM			
Gross Engine Power (PRP)	kW	56.00		
Gross Engine Power (Standby)	kW	61.60		
Manufacturer and Model		JCB 444 G-TC- 56		
Fuel		Diesel		
Injection		Direct		
Aspiration		Turbo Charged		
Cylinders		4		
Bore and Stroke	mm	103 x 132		
Displacement	L	4.399		
Cooling		Water		
Engine Oil Specification		API CH4-SAE 10W40		
Compression Ratio		17.5 : 1		
Engine Oil Capacity	L	14.00		
Coolant Capacity	L	16.00		
Governor		Mechanical		
Air Filter		Two stage filtration		
Engine Oil Consumption	100% Load	0.1% of fuel consumed		
FUEL SYSTEM				
Diesel Specification		EN590		

Battery Size (Ah)

Number of Batteries Battery Charger

Standard: •



ALTERNATOR ECP32-2M/4 B				
Poles			4	
Winding Connections		Star		
Insulation		Class H		
Enclosure		IP23		
Exciter System		Se	elf-regulating brushless	
Voltage Regulator			AVR	
Steady State Voltage Regulation			+/- 1.0%	
Bearing		Single bearing sealed		
Coupling		Flexible disc		
Cooling		Direct of	drive centrifugal blower fan	
Coating		Wi	inding Protection Grey	
STARTING SYSTEM				
Starter Motor	kW	/	4.20	
Battery Capacity	Ah		120	
Auxiliary Voltage	V		12	
BATTERY FEATURES				
Battery Isolator			Δ	
Battery Type (Optional)			Sealed Lead A	cid

Not Available: x

MECHANICAL FEATURES	
Cooling Pack	•
Air Filter	•
Mechanical Governor	•
Low Oil Pressure Sender	•
Coolant Temperature Sender	Δ
Low Oil Pressure Sensor	Δ
Oil Temperature Sender	•
Radiator Guards	•
Hot Component Guards	Δ
Water Jacket Heater	Δ
Pre-Filter with Separator	•
Internal Fuel Fill	•
3 Way Fuel Valve with Quick Connector	Δ
Industrial Silencer	•
Bunded Base	Δ
Gravity Oil Drain Pipe	Δ
Larger Fuel Filler Neck	Δ
Electronic Governor	×
Standard: • Not Available: x Optional: A	Δ

110

Δ

Optional: Δ



ELECTRICAL FEATURES			
AVR DSR			•
AVR DER			X
Winding Protection Standard			X
Winding Protection Standard +			X
Winding Protection Grey			•
Winding Protection Total			×
Winding Protection Total +			X
MAUX			•
PMG			X
Anti-Condensation Heater			Δ
3 Pole Moulded Case Circuit Breaker			•
4 Pole Moulded Case Circuit Breaker			Δ
Earth Leakage Protection (Shunt Trip)			•
Preparation for Earth Connection			•
Optional Voltages			Δ
Synchronisation			X
Emergency Stop Button			•
Fuel Level Sensor			•
Standard: ●	Not Available: x	Optional: 🛭	1

JCB COMMUNICATION AND CONTROL			
DSE 4520	•		
DSE 7320	Δ		
DSE 8610	X		
Live Link For Power	•		
CE PACK (Optional)			
EMC Certification	•		
Hot Guards	•		
Belt Guards	•		
Earth Leakage Relay	•		
Sound Power Decal	•		
EU Declaration for Engine Emissions			
Complete Machine Declaration of Conformity			

REFERENCE STANDARDS

JCB Generators are CE certified and conform to the following Directives (subject to a country requiring such standard):

- EN 12100, EN13857, EN60204
- 2006/42/CE Machinery safety
- 2006/95/EC Low voltage
- 2004/108/CE Electromagnetic compatibility
- 2000/14/EC Sound Power Level (amended by 2005/88/EC)
- 97/68/EC Emissions(amended by 2002/88/EC & 2004/26/EC)
- Power according to ISO 8528 and ISO 3046
- Ambient reference conditions 1000mbar, 25°C, 30% relative humidity ISO3046
 Information based on standard specification equipment unless otherwise stated.



WEIGHT AND DIMENSIONS – OPEN SET				
Length	mm	2300		
Width	mm	1030		
Height	mm	1750		
Shipping Volume (sea ready)	m ³	4.15		
Weight*	Kg	1360		
*Standard build with all fluids except fuel				

WEIGHT AND DIMENSIONS – CANOPY SET				
Length	mm	2750		
Width	mm	1140		
Height	mm	1850		
Shipping Volume (sea ready)	m ³	5.74		
Weight*	Kg	1660		
*Standard build with all fluids except fuel				

SOUND PRESSURE (CANOPY ONLY)				
LpA (7m)	50Hz	dB(A)	68	

FUEL SYSTEM		
Diesel Specification		EN590
Fuel Tank Capacity - Open	L	290
Fuel Tank Capacity - Canopy	L	270

CANOPY FEATURES	
Lockable Maintenance Access Doors	•
Control Panel Viewing Window	•
Fork Pockets	Δ
Single Lift Point	Δ
Bunding	Δ
High Density Fire Retardant Foam	•
Yellow Paint	•
White Paint	Δ
Four Point Lift (non CE)	Δ
Residential Silencer	•
Door Stops	Δ
Canopy Bump Stops	Δ
Manual Oil Drain Pump	Δ
1x32A 3 Phase / 1x16A 1 Phase Socket Box	X
1x63A 3 Phase / 3x32A Phase Socket Box	Δ
1x63A 3 Phase / 1x32A Phase / 2x16A Phase Socket Box	Δ
1x32A 3 Phase / 2x16A Phase Socket Box	Δ
IxI25A 3 Phase / Ix63A 3 Phase / 3x32A 3 Phase / 3x32A I Phase Socket Box	X
External Emergency Stop Button	•
Standard: ● Not Available: x Optional: Δ	Δ